# Forum:Hack Forums

Thread: Check This Before You Assume You're Ratted.

**Kekistan_Will_Thrive** - *May 19, 2017, 8:31 am*

First off, This is my first thread so go easy on me. ?

Does your mouse move erratically on it's own?

Even though this is particularly scary at first there's usually an easy enough explanation for it especially on Laptops. If your mouse moves by itself only when charging chances are that either your charger isn't getting enough amps to properly charge your battery (Usually caused by using extension cords or faulty chargers) which causes your mouse to register false clicks and touches, or you have a static charge build up/ground fault which can usually be solved by unplugging laptop, removing battery and holding the power button for 10 seconds.
Also check that your touchpad hasn't been exposed to moisture which can make it register false clicks and touches and that your touchpad sensitivity isn't set too high. Check if the mouse movement is stopped by using external mouse!
Hope this saves a few headaches and saves some unnecessary hard drive reformats! ?

**Sparkfear** - *May 19, 2017, 11:43 am*

Or you can request a check up which you can do in this section.